



Nelson & Nelson Mfg.
5210 Stadium Blvd. Suite C
Jonesboro AR 72404
870-268-6393 : Cell 219-1019

Installation Instructions 9-14-23
Model RYKR-FLRB22+

Steps needed to install your 2022 Ryker Rally Driver Floorboards Ryker Rally Model only 2022+

DO NOT USE IMPACT DRILL ON BOLTS OR NUTS.

(Stainless Steel Hardware is Softer Metal and can strip the threads.)

You must use lubricant on bolts and nuts to prevent galling. Minimum WD40, preferably Anti-Seize
Stainless Steel Lubricant MRO 1000



Complete Kit shown above. For Ryker Rally 2022+ Model Only.

1.- The New Spyder Extras Ryker Floorboard kit is simple to install and is the most comfortable floorboard option on the market. Set at an angle that fits the rider's position. This allows the floorboard to be tilted up and adjusted as the normal foot peg allowed.

First remove the support footrest off the foot oem foot peg.



2.- Locate the adapter spacer on the peg support as shown below. Using the holes in the spacer as a guide drill two 5/16" holes on each oem highway peg as shown below in this exact position. This hole location is based on the Spacer block as shown below. This block follows the configuration of the oem support foot peg once the actual lines up with the floorboard mount holes.



2.- Once both holes are drilled take the Floorboard support mount as shown below and locate the mount over the spacer on the foot peg. Take the two 5/16" Socket Head Bolts and place the floorboard main support over the footrest and take the mount lock plate flat side up and mount it from the bottom as shown below. Screw the bolts down evenly through the mount then the footrest into the mount lock plate. Tighten down evenly through the lock plate then add the safety locknuts as shown below.



3.- Before permanently securing the floorboards to their mounts adjust the floorboards to your riding position. This needs to be done before the floorboards are secured to the mounts. If you have more than one rider of the Ryker, the boards “only” will need to be removed each time by removing the two center screws to reset the peg mount locations for each rider. Then install the boards.

Take the floorboard plate with the letter R facing outwards and the two button heads screws and screw the floorboard plate down. Do the same for the opposite side.

Your Floorboards are now installed. These floorboards allow full adjustment of your existing OEM pegs.

4.-Once Installed do not stand on the rear of the Floorboards. Stand over the peg location only!



We thank you for purchasing one of our Ryker Accessory Kits. Today we know the need for accessories that provide a higher level of comfort while riding and we have solved that demand with a stylish system that compliments the design of your Ryker!

Spyderextras.com