

Nelson & Nelson Mfg. 5210 Stadium Blvd. Suite C Jonesboro AR 72404 870-268-6393: Cell 219-1019

Installation Instructions 2-7-22

Model SF3RT-RFLG

For all F3 Limited & 2020+ RT Limited Models

Steps needed to install your Rear Trunk Flag Kit



Complete Kit shown above.

1.- First take the provided paper template and cut along the black line as indicated. Then take the template and place on the rear trunk as shown and hold in place with tape. The template follows the trunks line for easy alignment. This flag holder can be installed on either side of the trunk.



2.- Notice the two-hole locations on the template. You will need a Step Drill bit. Am 1/8", 11/32" & 7x32" drill bits. Use the 1/8" drill bit first and drill a pilot hole on the center of each drill hole location on the template. Then take the correct size drill bit and drill the proper size hole shown on the template. The 11/32" hole you will drill straight through the trunk to come out on the inside of the trunk. Raise your trunk lid to verify when the hole comes through. The 7/32 hole ONLY goes through the outside of the trunk. DO NOT DRILL THIS HOLE ALL THE WAY THOUGH TO THE INSIDE OF THE TRUNK.

Then take the step drill bit to enlarge the hole on the inside of the trunk panel only to fit the 5/8" diameter spacer provided. The hole should be just a bit larger than the spacer only.



3.-Locate the bolt washer and spacer. Take the washer, place it on the bolt then add the spacer. Place through the hole as shown above then apple the flag holder to the outer trunk side once the paper template is removed.



4.- Once the flag is located on the outside as shown above tighten down the inside bolt to secure the flag in place. The small flag holder 7/32 hole is for a stub that prevents the flag from moving once tightened down.

Your new Flag is now installed.

We thank you for purchasing one of our F3 / RT Accessory Kits. Today we know the need for accessories that provide a higher level of comfort while riding and we have solved that demand with a stylish system that compliments the design of your Spyder!