



Nelson & Nelson Mfg.
5210 Stadium Blvd, Suite C
Jonesboro AR 72404
870-268-6393 : Cell 219-1019

Installation Instructions
3-16-23

Model SF3RT-USB-1

**12 VOLT ADD-ON 90 DEG PLATE-DUAL USB SOCKET. MOUNTS
ON RAM MOUNT ARMS.**

Steps needed to install your 12-volt unit.

- 1.- This unit installs over the 1/4" bolt that is located on the twist knob of a ram mount arm product.
- 2.- remove twist knob and place 12-volt unit over the bolt of the ram mount or run the bolt of the knob through the mount hole. Place the 12-volt socket at ant position that works best with the ram mount arm assuring easy access to the dual USB sockets.
- 3.-Run power wires to a fused power location on your Spyder.



The Mount Arm above is NOT included shown for install only.

We thank you for purchasing of our 12-volt power stations products. Today we know the needs for 12-volt power for accessories and we have solved that demand with a stylish system that compliments the design of your Spyder!

spyderextras.com