



Nelson & Nelson Mfg.
5210 Stadium Blvd, Suite C
Jonesboro AR 72404
870-268-6393 : Cell 219-1019

Installation Instructions 7-6-22

Model SPX-DRVL

Spyder Extras Driving LED Fog Lights

Steps needed to install your LED Fog Lights

1.- This Light Kit can be installed in several locations on your Spyder or Ryker. Choose your location. Run the Power wires directly to the Battery making sure the Red is on Positive and Black is on Negative.

Be sure to run the wire harness away from moving parts or engine areas not to get hot. The switch can be mount using one of the screw locations on your handlebar control modules for easy access.

2.- The hole required to mount each light is a minimum 5/16" clear hole.



We thank you for purchasing one of our 12-volt accessories. Today we know the needs for 12-volt power for accessories and we have solved that demand with a stylish system that compliments the design of your Spyder or Ryker®!

spyderextras.com