



**Nelson & Nelson Mfg.**  
5210 Stadium Blvd, Suite C  
Jonesboro AR 72404  
870-268-6393 : Cell 219-1019

Installation Instructions 6-6-22

**Model SPX-HBR**

**Spyder Extras Handlebar Riser Kit**

**Steps needed to install your Handlebar Riser**



**1.- First remove the 4 Socket Head Bolts that hold your Handlebar cap in place and move the handlebars down out of the way shown below on left Photo. Next take the new Handlebar riser and place over the lower mount as shown n the right photo below.**



**2.- Next take handlebars and relocate them as they were in the new cradle of the new riser, install the oem cap and use the new 4 socket head bolts. Use Blue Loctite on these 4 bolts and secure them in place making sure before you tighten them down securely that the handlebar position is correct. Sit on the Spyder and adjust the position of the handlebars to your comfort and then tighten down the top bolts snug then the bottom bolts then all four bolts evenly.**

**This kit matches the OEM design and paint for a seamless look & fit!**



**We thank you for purchasing one of our Spyder accessories. Today we know the needs for quality accessories, and we have solved that demand with a stylish system that compliments the design of your Spyder or Ryker®!**

[spyderextras.com](http://spyderextras.com)